


# DVC 821/M4 MODUL

## 1. DVC 821/M4 modul



### Pozivne šifre

DVC DT821 automatski dodjeljuje pozivne šifre tipkama povezanih modula. Bez obzira na strukturu modula sa pozivnim tipkama brojevi tipki idu odozdol prema gore:

Pozivna šifra	DIP raspored	Pozivna šifra	DIP raspored	Pozivna šifra	DIP raspored
04 03 02 01	08 07 06 05	12 11 10 09	20 19 18 17	24 23 22 21	16 15 14 13

# DVC 821/M4 MODUL

Pozivna šifra	DIP raspored	Pozivna šifra	DIP raspored	Pozivna šifra	DIP raspored
